

# WindSigns

## ASSEMBLY INSTRUCTIONS

1. Remove fill hole cap from base and fill with sand or water. Play sand is recommended for ease of filling. Water may be used at temperatures above freezing.
2. After filling, stand base on its side.
3. Put a washer on a bolt and push through one of the holes at the bottom of the base, hold in place while you screw the spring onto the bolt from the top of the base. Tighten spring and bolt securely.
4. Repeat with second, bolt, washer, and spring.
5. Slide frame onto rods, through frame receptacles #1.
6. Place collars on rods as they slide through frame receptacles #2.
7. Push frame down so that the top of the rods meet the top of frame receptacle #2.
8. Tighten collars with the allen wrench.

