



BASE-X

BANNER STANDS

- A. Item '1' is the Crossing Basement or Feet.
- B. Items '2' are the Banner Graphic Attachment Bars.
- C. Item '3' is the Bottom Banner Stand Pole has the "Hook and Spring Attachment" as seen on insert 'A'.
- D. Item '4' is the Top Banner Stand Pole and has the 'Double Bar Holder' on top of the pole.



2 lbs. 15 oz.

**Suggested banner size
23.75" X up to 73"**

1. Connect the top and bottom poles.
2. Attach the bottom pole to the Crossing Basement per insert B.
3. Remove the plastic End Cap from either end of the Banner Graphic Attachment Bars.
4. Withdraw the adhesive strips which are inside the Bars.
5. Align the graphic onto the adhesive-backed plastic strips.
6. Attach the back of the graphic to the front of the adhesive-backed plastic strips.
7. After graphic has been attached to the adhesive strip, slide the adhesive strip with the graphic back into the Banner Graphic Attachment Bars, per insert E.
8. Slide the top Banner Graphic Attachment Bars into the plastic Double Bar Holder.
9. Recap the Banner Graphic Attachment Bars with the plastic End Caps.
10. Attach the bottom Banner Graphic Attachment Bar onto the Hook and Spring Attachment, and adjust the length accordingly.

FELLERS
America's Largest Vinyl Sign Supply Company

Ph: 1-800-654-8405 Fax: 1-888-405-4548
sales.service@fellers.com